

Feed a hungry child for FREE in just seconds,SECONDS !!!
<http://www.thehungersite.com>

FACTORY RESET PROCEDURES / RESET SEQUENCES

10/07/04

MAKE MODEL

=====

ALESIS ADAT
HOLD PLAY AND RECORD WHILE POWERING ON. { "DRUM
ON" HRS WILL NOT BE RESET. }

ALESIS ADAT-LX-20
HOLD RECORD WHILE POWERING ON. { "DRUM ON" HRS
WILL NOT BE RESET. }

ALESIS ADAT-XT
HOLD PLAY AND RECORD WHILE POWERING ON. { "DRUM
ON" HRS WILL NOT BE RESET. }

ALESIS ADAT-XT-20
HOLD PLAY AND RECORD WHILE POWERING ON. { "DRUM
ON" HRS WILL NOT BE RESET. }

ALESIS AI-2
HOLD STORE WHILE POWERING ON. { ADAT TAPE HEAD
INFO WILL ALSO BE CLEARED. }

ALESIS BRC
HOLD PLAY AND RECORD WHILE POWERING ON.

ALESIS D4
HOLD VOICE AND OUTPUT WHILE POWERING ON.

ALESIS DM5
HOLD VOICE AND OUTPUT WHILE POWERING ON.

ALESIS HR-16
HOLD ERASE, DELETE AND RECORD WHILE POWERING ON.

ALESIS HR-16B
HOLD ERASE, DELETE AND RECORD WHILE POWERING ON.

ALESIS M-20
HOLD PLAY AND RECORD WHILE POWERING ON. { "DRUM
ON" HRS WILL NOT BE RESET. }

ALESIS MIDIVERB 4
HOLD 'D' AND 'PROG' WHILE POWERING ON.

ALESIS MIDIVERB III
HOLD STORE AND INT PROG WHILE POWERING ON.

ALESIS MMT-8
HOLD ERASE, PAGE UP AND PAGE DOWN WHILE POWERING
ON.

ALESIS Q-20
SOFT RESET: HOLD PROGRAM AND COMPARE AND POWER O
N. (SETS GLOBAL TO DEFAULT, CLEARS EDIT BUFF
ER, LEAVES USER MEMORY INTACT.)

ALESIS Q-20
HARD RESET: HOLD "PROGRAM", "COMPARE" AND "-BLOC
K" AND POWER ON. (SETS ALL FUNCTIONS TO DEFA
ULT AND CLEARS USER MEMORY.)

ALESIS QS6
HOLD KEYPADS '0' AND '3' WHILE TURNING ON POWER.

ALESIS QS6 KEYBOARD
HOLD KEYPADS '0' AND '3' WHILE TURNING ON POWER.

ALESIS QS7
HOLD KEYPADS '0' AND '3' WHILE TURNING ON POWER.

ALESIS QS8
HOLD KEYPADS '0' AND '3' WHILE TURNING ON POWER.

ALESIS QSR
HOLD BOTH SIDES OF "CURSOR" BUTTON WHILE POWERIN
G ON.

ALESIS QUADRASYNTH KBDS
HOLD DATA BUTTONS '1' AND '4' WHILE POWERING ON.
(CLEARS EDIT BUFFER ONLY; THERE IS NO HARD
RESET.)

ALESIS QUADRAVERB
HOLD BYPASS AND PROGRAM THEN POWER ON.

ALESIS QUADRAVERB 2
SOFT RESET: HOLD PROGRAM AND COMPARE AND POWER O
N. (SETS GLOBAL TO DEFAULT, CLEARS EDIT BUFF
ER, LEAVES USER MEMORY INTACT.)

ALESIS QUADRAVERB 2
HARD RESET: HOLD "PROGRAM", "COMPARE" AND "-BLOC
K" AND POWER ON. (SETS ALL FUNCTIONS TO DEFA
ULT AND CLEARS USER MEMORY.)

ALESIS QUADRAVERB GT
HOLD BYPASS AND PROGRAM WHILE TURNING ON THE POW
ER.

ALESIS S4 SOUND MODULE
HOLD DATA BUTTONS '1' AND '4' WHILE POWERING ON.
(CLEARS EDIT BUFFER ONLY; THERE IS NO HARD
RESET.)

ALESIS S8 SOUND MODULE
HOLD DATA BUTTONS '1' AND '4' WHILE POWERING ON.
(CLEARS EDIT BUFFER ONLY; THERE IS NO HARD
RESET.)

ALESIS SR-16
HOLD PLAY AND ERASE WHILE TURNING ON POWER.

ALESIS WEDGE
HOLD BYPASS AND PROG WHILE TURNING ON THE POWER.

ALESIS X2 CONSOLE
HOLD 'ALT', 'ERASE FWD' AND 'DEC' WHILE POWERING
ON. (THIS IS SOFT RESET; FACTORY MUTE PARAM
ETERS WILL BE LOADED INTO MEMORY.)

ART ALPHA
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART ALPHA 2.0
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART BCC
HOLD STORE, PARAMETER, AND VALUE BUTTONS + POWER
ON.

ART DRX
PRESS PRESET DOWN, 0, AND 4 BUTTONS SIMULTANEOUS
LY.

ART DRX 2100
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART DRX 2100 SE

PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART DST 820
PRESS PREAMP SELECT, PARAMETER SELECT, AND SAVE
SIMULTANEOUSLY.

ART DST 830
PRESS PREAMP SELECT, PARAMETER SELECT, AND SAVE
SIMULTANEOUSLY.

ART DST-4
PRESS DISTORTION SELECT, PARAMETER EDIT, AND SAV
E SIMULTANEOUSLY.

ART DST-EIGHTY/EIGHTY
PRESS DISTORTION SELECT, PARAMETER EDIT, AND SAV
E BUTTONS SIMULTANEOUSLY.

ART DXR ELITE
PRESS BANK, SOFT KEY, AND BYPASS BUTTONS SIMULTA
NEOUSLY.

ART ECC
HOLD STORE, PARAMETER, AND VALUE BUTTONS + POWER
ON.

ART EFFECTS NETWORK
PRESS VALUE, SAVE, AND BYPASS BUTTONS SIMULTANEO
USLY.

ART FXR ELITE
PRESS PRESET UP, DRY KILL, AND BYPASS BUTTONS SI
MULTANEOUSLY.

ART FXR ELITE II
PRESS MIX, STORE, AND BYPASS BUTTONS SIMULTANEOU
SLY.

ART MULTIVERB
PRESS PRESET DOWN, 0, AND 4 SIMULTANEOUSLY.

ART MULTIVERB ALPHA SE
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART MULTIVERB EXT
PRESS PRESET DOWN, 0, AND 4 SIMULTANEOUSLY.

ART MULTIVERB II
PRESS PRESET DOWN, 0, AND 4 SIMULTANEOUSLY.

ART MULTIVERB III
PRESS PRESET DOWN, 0, AND 4 BUTTONS SIMULTANEOUS
LY.

ART MULTIVERB LT
no factory reset, remove battery for more than 5 hours.

ART MULTIVERB LTX
no factory reset, remove battery for more than 5 hours.

ART NIGHT BASS
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART NITRO
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART PRO GATE
PRESS BYPASS, 8, AND SELECT SIMULTANEOUSLY.

ART PROVERB
no factory reset. remove battery for more than 5 hours.

ART PROVERB 200
no factory reset. remove battery for more than 5 hours.

ART RXR ELITE
PRESS BANK, DRY KILL, AND BYPASS BUTTONS SIMULTA
NEOUSLY.

ART SGE
HOLD PRESET DOWN, ADD EFFECT, AND MIDI/UTILITY W
HILE POWERING ON.

ART SGE MACH II
PRESS PRESET DOWN, 0, AND 4 BUTTONS SIMULTANEOUS
LY.

ART SGX 2000
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART SGX 2000 EXPRESS
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART SGX LT
no factory reset, remove battery for more than 5 hours.

ART SGX NIGHTBASS SE
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART SGX T2
PRESS PRESET, 0, AND 4 BUTTONS SIMULTANEOUSLY.

ART X12
PRESS UP, 2, AND 5 PADS SIMULTANEOUSLY.

ART X15 ULTRAFOOT
PRESS UP, 1, AND 5 PADS SIMULTANEOUSLY.

DIGITECH DHP 33
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY REST
ORE MENU, TURN EITHER DATA KNOB COUNTER-CLOCK
WISE, THEN PRESS STORE.

DIGITECH DHP 55
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY REST
ORE MENU, PRESS PARAMETER EDIT, THEN LOAD.

DIGITECH DSP 128
HOLD PARAMETER EFFECT AND SELECT, THEN POWER ON.

DIGITECH DSP 128+
HOLD PARAMETER DOWN AND LEFT, THEN POWER ON.

DIGITECH DSP 256
HOLD UTILITY, POWER ON, THEN PRESS PARAMETER UP.

DIGITECH DSP 256XL
HOLD UTILITY, POWER ON, THEN PRESS PARAMETER UP.

DIGITECH FX 7
PRESS/HOLD STORE, POWER ON, WAIT UNTIL "RS" APPE
ARS IN THE DISPLAY THEN RELEASE STORE.

DIGITECH G7
PRESS AND HOLD PROGRAM, POWER ON THEN PRESS THE
STORE BUTTON.

DIGITECH GFX 1
HOLD UTILITY BUTTON, POWER ON, THEN PRESS PARAME
TER UP.

DIGITECH GSP 21
HOLD TITLE BUTTON, POWER ON.

DIGITECH GSP 21 LEGEND
HOLD UTILITY BUTTON, POWER ON, THEN PRESS PARAME
TER UP.

DIGITECH GSP 21 PRO
HOLD UTILITY BUTTON, POWER ON, THEN PRESS PARAMETER UP.

DIGITECH GSP 2112
HOLD THE PREAMP BUTTON, POWER ON. WHEN THE ASTERISK APPEARS IN THE TOP OF THE DISPLAY, PRESS THE MOD BUTTON.

DIGITECH GSP 5
HOLD PARAMETER DOWN THEN POWER ON.

DIGITECH GSP 7
HOLD UTILITY BUTTON, POWER ON, THEN PRESS PARAMETER UP.

DIGITECH GSP2101
HOLD ACCESS 1 BUTTON, POWER ON. AFTER * APPEARS IN THE UPPER LEFT OF THE LCD PRESS PROGRAM UP

DIGITECH IPS 33
HOLD BOTH FUNCTION SELECT BUTTONS THEN POWER ON.

DIGITECH IPS 33B
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY RESTORE MENU, PRESS PARAMETER DOWN, THEN STORE.

DIGITECH LEGEND II
HOLD STORE, POWER ON. AFTER * APPEARS IN THE UPPER LEFT CORNER OF THE LCD PRESS PARAMETER UP.

DIGITECH MEQ 14
HOLD PROGRAM BUTTON THEN POWER ON.

DIGITECH MEQ 28
HOLD PROGRAM BUTTON THEN POWER ON.

DIGITECH MEQ 7
HOLD PROGRAM BUTTON THEN POWER ON.

DIGITECH MSP 4
HOLD THE DOWN AND LEFT BUTTONS THEN POWER ON.

DIGITECH PMC 10
PRESS AND HOLD FOOTSWITCH "ONE", POWER ON, THEN PRESS THE "SELECT" FOOTSWITCH.

DIGITECH RP 1

HOLD UTILITY BUTTON, POWER ON, THEN PRESS PARAMETER UP.

DIGITECH RP 10
HOLD NAME, POWER ON. AFTER * APPEARS IN THE UPPER LEFT CORNER OF LCD PRESS PROGRAM UP.

DIGITECH RP 12
HOLD NAME, POWER ON. AFTER * APPEARS IN THE UPPER LEFT CORNER OF LCD PRESS PROGRAM UP.

DIGITECH RP 5
HOLD PARAMETER SELECT UP BUTTON THEN POWER ON.

DIGITECH RP 6
HOLD PARAMETER SELECT UP BUTTON THEN POWER ON.

DIGITECH S-5000
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY RESTORE MENU, PRESS PARAMETER EDIT, THEN LOAD.

DIGITECH STUDIO 400
PRESS AND HOLD THE "1" BUTTON, POWER ON. WHEN THE ASTERISK APPEARS IN THE TOP OF THE DISPLAY, PRESS PROGRAM.

DIGITECH STUDIO QUAD
PRESS AND HOLD THE "1" BUTTON, POWER ON. WHEN THE ASTERISK APPEARS IN THE TOP OF THE DISPLAY, PRESS PROGRAM.

DIGITECH SV 5
PRESS UTILITY BUTTON, SELECT THE INIT MENU, PRESS THE STORE BUTTON TWICE (AS PROMPTED).

DIGITECH TEC 8
PRESS AND HOLD BOTH LOW EQ AND MID EQ, POWER ON.

DIGITECH TSR 12
HOLD NAME + POWER ON. AFTER * APPEARS IN THE UPPER LEFT CORNER OF LCD PRESS PROGRAM UP.

DIGITECH TSR 24
HOLD ACCESS 1 BUTTON, POWER ON. AFTER * APPEARS IN THE UPPER LEFT OF THE LCD PRESS PROGRAM UP

.

DIGITECH TSR 6
PRESS AND HOLD EQ BUTTON, POWER ON. WAIT FOR "FA

" TO APPEAR IN THE DISPLAY THEN PRESS STORE.
NOTE: "FH" WILL APPEAR BRIEFLY TO ACKNOWLEDGE RE-INITIALIZATION.

DIGITECH VALVE FX
HOLD STORE, POWER ON. AFTER * APPEARS IN THE UPPER LEFT CORNER OF LCD PRESS PARAMETER UP.

DIGITECH VHM 5
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY RESTORE MENU, PRESS PARAMETER DOWN, THEN STORE.

DIGITECH VOCALIST II
PRESS UTILITY BUTTON, SCROLL TO THE FACTORY RESTORE MENU, PRESS PARAMETER DOWN, THEN STORE.

DIGITECH XP PEDALS
PRESS/HOLD THE BYPASS/(HOLD)TUNER FOOTSWITCH AND POWER ON.

ENSONIQ DP-PRO
HOLD SYSTEM BUTTON AND PRESS CANCEL. RELEASE BOTH BUTTONS, PRESS ENTER.

ENSONIQ DP/2
HOLD SYSTEM/MIDI AND PRESS THE "B" BUTTON, THEN RELEASE BOTH. PRESS RIGHT ARROW ONCE. PRESS WRITE BUTTON AT PROMPT.

ENSONIQ DP/4
HOLD SYSTEM/MIDI AND PRESS THE "B" BUTTON, THEN RELEASE BOTH. PRESS RIGHT ARROW ONCE. PRESS WRITE BUTTON AT PROMPT.

ENSONIQ DP/4+
HOLD SYSTEM/MIDI AND PRESS THE "B" BUTTON, THEN RELEASE BOTH. PRESS RIGHT ARROW ONCE. PRESS WRITE BUTTON AT PROMPT.

ENSONIQ ESQ-M
PRESS PARAM, PRESS STORAGE. HOLD SCROLL, PRESS MASTER. RELEASE BOTH, SCROLL TO SELECT MEMORY PRESET PAGE. HOLD SCROLL, PRESS STORAGE. RELEASE BOTH, PRESS ([).

ENSONIQ FIZMO
HOLD THE SAVE BUTTON AND PRESS COMPARE. PRESS THE YES BUTTON AT THE PROMPT.

ENSONIQ FIZMO RACK
HOLD THE SAVE BUTTON AND PRESS COMPARE. PRESS THE

E YES BUTTON AT THE PROMPT.

ENSONIQ KS-32
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD B
ANK 9 (SYSTEM) AND THEN PRESS SCREEN 9. RELEA
SE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ KT-76
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD T
HE UPPER 9 BUTTON AND THEN PRESS THE LOWER 9.
RELEASE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ KT-88
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD T
HE UPPER 9 BUTTON AND THEN PRESS THE LOWER 9.
RELEASE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ MR-61/76
HOLD THE ERASE BUTTON (IN THE SONG EDITOR SECTIO
N) AND POWER ON.

ENSONIQ MR-RACK
HOLD SAVE AND PRESS ENTER, THEN PRESS ENTER AT T
HE PROMPT.

ENSONIQ SD-1
HOLD PRESET BUTTON AND PRESS SOFT #1 BUTTON (UPP
ER LEFT CORNER OF SCREEN). RELEASE BOTH, PRES
S YES AT THE PROMPT.

ENSONIQ SQ-1 (21 VOICE)
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD B
ANK 9 (SYSTEM) AND THEN PRESS SCREEN 9. RELEA
SE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ SQ-1/32
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD B
ANK 9 (SYSTEM) AND THEN PRESS SCREEN 9. RELEA
SE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ SQ-2 (21 VOICE)
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD B
ANK 9 (SYSTEM) AND THEN PRESS SCREEN 9. RELEA
SE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ SQ-2/32
PRESS EDIT/SEQUENCES (PRESETS). PRESS AND HOLD B
ANK 9 (SYSTEM) AND THEN PRESS SCREEN 9. RELEA
SE BOTH AND PRESS YES AT THE PROMPT.

ENSONIQ SQ-80
HOLD THE RECORD BUTTON AND PRESS THE #1 SOFT BUT
TON (UPPER LEFT CORNER OF SCREEN). RELEASE BO
TH BUTTONS, PRESS YES AT THE PROMPT.

ENSONIQ SQ-R
HOLD SYSTEM BUTTON. QUICKLY PRESS "NO" THEN RELE
ASE BOTH BUTTONS. PRESS YES AT PROMPT.

ENSONIQ TS-10
HOLD PRESETS BUTTON AND PRESS SOFT 1 BUTTON (UPP
ER LEFT CORNER OF DISPLAY). RELEASE BOTH BUTT
ONS. SELECT YES AT THE PROMPT.

ENSONIQ TS-12
HOLD PRESETS BUTTON AND PRESS SOFT 1 BUTTON (UPP
ER LEFT CORNER OF DISPLAY). RELEASE BOTH BUTT
ONS. SELECT YES AT THE PROMPT.

ENSONIQ VFX
HOLD PRESETS BUTTON, PRESS SOFT 1 BUTTON (UPPER
LEFT CORNER OF SCREEN). SELECT YES AT PROMPT.

ENSONIQ VFX/SD
HOLD PRESET BUTTON AND PRESS SOFT #1 BUTTON (UPP
ER LEFT CORNER OF SCREEN). RELEASE BOTH, PRES
S YES AT THE PROMPT.

ENSONIQ ZR-76
HOLD THE ERASE BUTTON (IN THE SONG EDITOR SECTIO
N) AND POWER ON.

KORG 01W
HOLD RESET AND COMPARE THEN POWER ON.

KORG 01WFD
HOLD RESET AND COMPARE THEN POWER ON.

KORG A1
HOLD WRITE AND -1 THEN POWER ON.

KORG A2
HOLD DOWN ARROW AND UP ARROW, POWER ON, PRESS "E
" (YES).

KORG A3
HOLD DOWN ARROW AND UP ARROW, POWER ON, PRESS "E
" (YES).

KORG A4
HOLD WRITE AND BYPASS, THEN POWER ON.

KORG AM8000-R
HOLD FX1 AND FX2 THEN POWER ON.

KORG C-505
MIDI/TRANSPOSE + SPLIT AND RESTART UNIT.

KORG DDD-1
HOLD YES AND NO, THEN POWER ON.

KORG DL8000-R
HOLD "MS/D" AND "HOLD", THEN POWER ON.

KORG DS-8/707
HOLD UP AND DOWN, THEN POWER ON.

KORG I1
HOLD PROGRAM AND DISK, THEN POWER ON.

KORG I2
HOLD ARR PLAY AND EDIT STYLE THEN POWER ON.

KORG I3
HOLD ARR PLAY AND EDIT STYLE THEN POWER ON.

KORG I30
HOLD ARRANGE PLAY AND GLOBAL, THEN POWER ON.

KORG I4S
HOLD ARR. PLAY AND PROGRAM, THEN POWER ON.

KORG I5M
HOLD ARR. PLAY AND GLOBAL, THEN POWER ON.

KORG I5S
HOLD ARR. PLAY AND GLOBAL, THEN POWER ON.

KORG IH
HOLD DETUNE AND BASS, THEN POWER ON.

KORG IS40/50/I40M
HOLD ARR. PLAY AND GLOBAL, THEN POWER ON.

KORG KARMA
HOLD ENTER AND 0, THEN POWER ON.

KORG M1
HOLD INT, CARD, AND COMBI THEN POWER ON.

KORG M1R
HOLD INT, PROG, AND COMBI THEN POWER ON.

KORG M3R
PAGE 5D OF GLOBAL MODE.

KORG N264
HOLD ENTER AND 7, THEN POWER ON.

KORG N364
HOLD ENTER AND 7, THEN POWER ON.

KORG O5RW
HOLD +1 AND -1 THEN POWER ON.

KORG SG-PROX
HOLD PROGRAM AND PIANO 1, THEN POWER ON.

KORG SG-RACK
HOLD EDIT AND A4, THEN POWER ON.

KORG T SERIES
HOLD LOWER KEYPAD 0 AND PROG A, POWER ON, AND THEN IMMEDIATELY TURN OFF.

KORG TR-RACK
HOLD EDIT AND A4, THEN POWER ON.

KORG TRITON
HOLD ENTER AND 0, THEN POWER ON.

KORG TRITON RACK
HOLD ENTER AND 0, THEN POWER ON.

KORG X3
HOLD ENTER AND CURSOR DOWN THEN POWER ON.

KORG X3R
HOLD ENTER AND CURSOR DOWN THEN POWER ON.

KORG X5
HOLD +1 AND -1, THEN POWER ON.

KORG X5D
HOLD +1 AND -1 THEN POWER ON.

KORG X5DR
HOLD +1 AND -1 THEN POWER ON.

KORG Z1
HOLD SW1 AND SW2, THEN POWER ON.

KORG Z1EX
HOLD SW1 AND SW2, THEN POWER ON.

KURZWEIL K2000
HOLD "1", "2" AND "3" BUTTONS AND POWER ON. AFTE
R POWER UP PRESS ENTER.
{EXCEPT V1.0 OS }

KURZWEIL K2000
OS VERSION 1.0: POWER OFF AND UNPLUG. REMOVE BA
TTERIES FOR @ 60-90 MINUTES. REINSTALL BATTER
IES. POWER ON.

KURZWEIL K2500
AT POWER ON WHEN SCREEN DISPLAYS "PLEASE WAIT" P
RESS THE EXIT BUTTON. AT MENU, SELECT HARD RE
SET AND FOLLOW DIRECTIONS.

OBERHEIM MATRIX-6
HOLD STORE WHILE POWERING ON.

PEAVEY ADDVERB
HOLD THE - AND 5 KEYS THEN POWER ON.

PEAVEY ADDVERB II
HOLD THE - AND 5 KEYS THEN POWER ON.

PEAVEY ADDVERB III
HOLD THE ADD/DEL AND GLOBAL BUTTONS, POWER ON.

PEAVEY AEQ 2800
HOLD THE MIDI AND ASSIGN KEYS THEN POWER ON.

PEAVEY AUTOGRAPH
HOLD THE MIDI AND ASSIGN KEYS THEN POWER ON.

PEAVEY BASSFEX
HOLD THE PLAY AND GLOBAL BUTTONS THEN POWER ON.

PEAVEY CEQ 28
HOLD THE MIDI AND ASSIGN KEYS THEN POWER ON.

PEAVEY CEX 4

HOLD THE MASTER AND STORE/MEMORY BUTTONS THEN POWER ON.

PEAVEY CEX 4L
HOLD THE MASTER AND STORE/MEMORY BUTTONS THEN POWER ON.

PEAVEY CYBERBASS (MODULE)
HOLD THE PROGRAM AND RIGHT CURSOR BUTTONS THEN POWER ON.

PEAVEY DPM 2
HOLD 0 BUTTON, PRESS ENTER. RELEASE BOTH BUTTONS AND PRESS ENTER.

PEAVEY DPM 4
HOLD SAVE BUTTON, PRESS PAUSE. PRESS ENTER WHEN PROMPTED.

PEAVEY DPM C8
HOLD THE 0 AND ENTER BUTTONS, POWER ON, WAIT FOR THE "UNIT INITIALIZED" DISPLAY THEN RELEASE THE BUTTONS.

PEAVEY DPM C8P
HOLD THE 0 AND COPY BUTTONS, POWER ON, WAIT FOR THE "UNIT INITIALIZED" DISPLAY THEN RELEASE THE BUTTONS.

PEAVEY DPM SI
TURN POWER ON. HOLD '0' AND PRESS ENTER. PRESS ENTER AT THE PROMPT TO RE-INITIALIZE KEYBOARD.

PEAVEY DSR 1000
HOLD THE - AND 5 KEYS THEN POWER ON.

PEAVEY LIBRARIAN
HOLD LOAD, SAVE, AND UTIL BUTTONS AND POWER ON.

PEAVEY MAP 8X4
HOLD BYPASS + POWER WHILE PLUGGING UNIT IN.

PEAVEY MFP 2128/MIDI MANA
HOLD + AND - KEYS THEN POWER ON.

PEAVEY MIDI MANAGER
HOLD + AND - KEYS THEN POWER ON.

PEAVEY MIDI MASTER

HOLD FUNCTION AND PROC A KEYS THEN POWER ON.

PEAVEY MIDI MASTER II
HOLD FUNCTION AND PROC A KEYS THEN POWER ON.

PEAVEY MIDI STREAMER
HOLD THE RECORD (SYSX, SAMP, + SEQ) KEYS AND POWER ON. AT PROMPT PRESS START TO RE-INITIALIZE
.

PEAVEY MULTIFEX
HOLD THE 2 KEYS NEXT TO DISPLAY AND POWER ON.

PEAVEY PC 1600
HOLD THE UTILITY + ENTER KEYS AND POWER ON.

PEAVEY PC4-X
HOLD THE MASTER + MIDI KEYS AND POWER ON.

PEAVEY PC4-XL
HOLD THE MASTER + MIDI KEYS AND POWER ON.

PEAVEY PGP 20
HOLD THE A/B + MUTE KEYS AND POWER ON.

PEAVEY PLM 8128
PRESS TWO RIGHT-MOST SOFT KEYS IN BOTTOM ROW AND POWER ON. (VCA CAL UNAFFECTED)

PEAVEY PLM 8128E
HOLD THE SOLO AND MUTE KEYS, POWER ON. (VCA CAL UNAFFECTED)

PEAVEY PROFEX
HOLD THE PLAY AND MIDI KEYS THEN POWER ON.

PEAVEY PROFEX II
HOLD THE PLAY AND GLOBAL BUTTONS, POWER ON.

PEAVEY PROGRAMAX
HOLD THE A/B AND MUTE KEYS THEN POWER ON.

PEAVEY PV LITE 3000
FACTORY PRESETS: HOLD CHASE + AUTO SOUND, POWER ON. HARD RESET: HOLD DOWN + STORE, POWER ON.
IN BOTH CASES, HOLD UNTIL 00 APPEARS IN THE DISPLAY.

PEAVEY SDR 20/20
HOLD THE PLAY AND STORE KEYS WHILE POWERING ON.

PEAVEY SPECTRUM ANALOG FI
HOLD THE DEC AND EXEC BUTTONS, POWER ON. (TO IN
IT. FOR USE W/ CYBERBASS, HOLD DEC AND BYPASS
THEN POWER ON.

PEAVEY SPECTRUM BASS II
HOLD THE + AND - BUTTONS THEN POWER ON.

PEAVEY SPECTRUM ORGAN
HOLD THE + AND - BUTTONS THEN POWER ON.

PEAVEY SPECTRUM SYNTH
HOLD THE + AND - BUTTONS THEN POWER ON.

PEAVEY ULTRAVERB
HOLD THE - AND 5 KEYS THEN POWER ON.

PEAVEY ULTRAVERB II
HOLD THE + AND 9 BUTTONS THEN POWER ON.

ROLAND A-220
HOLD B AND MEMORY THEN POWER ON.

ROLAND A-30
HOLD WRITE WHILE POWERING ON (30 SECONDS)

ROLAND A-33
HOLD WRITE WHILE POWERING ON (30 SECONDS)

ROLAND A-37
HOLD WRITE BUTTON AND POWER ON. DISPLAY SHOWS FA
CTORY SETUP AT COMPLETION.

ROLAND A-50
HOLD 1ST+3RD+4TH BUTTONS UNDER DISPLAY, PRESS CH
ANNEL, THEN PRESS ANY CURSOR KEY.

ROLAND A-80
HOLD 1ST+3RD+4TH BUTTONS UNDER DISPLAY, PRESS CH
ANNEL, THEN PRESS ANY CURSOR KEY.

ROLAND A-880
HOLD SIGNAL AND MEMORY THEN POWER ON.

ROLAND A-90
HOLD EDIT, POWER ON THEN PRESS ENTER. WITH VOICE
EXPANDER BOARD: HOLD MANUAL, POWER ON, THEN
PRESS ENTER.

ROLAND A90EX
HOLD MANUAL BUTTON AND POWER ON. THEN PRESS ENTER.
R.

ROLAND ADA-8024
no rom reset.

ROLAND ALPHA JUNO-1
no rom reset.

ROLAND ALPHA JUNO-2
no rom reset.

ROLAND AP-700
PWR ON, EXIT REPEATEDLY TO ANALYZER/FILTER SCREEN.
N. CURSOR TO: MENU + ENTER, SYSTEM + ENTER, INIT
NIT + ENTER. USE VALUE SELECT ALL THEN EXEC + ENTER TWICE.

ROLAND AR SERIES
no rom reset.

ROLAND AT SERIES
HOLD ONE TOUCH PROGRAM + POWER ON.

ROLAND AX-1
HOLD WRITE BUTTON + POWER ON (HOLD 30 SECONDS).

ROLAND AXIS-1
POWER ON. HOLD FUNCTION; PRESS F#0, C#2, AND D#2
KEYS.

ROLAND CA-30
RESETS EVERY TIME TOGGLED OFF AND THEN ON.

ROLAND CDX1
PRESS UTILITY. CURSOR RIGHT, SELECT INIT AND PRESS
ENTER THEN CURSOR TO GLOBAL. PRESS ENTER THREE
TIMES.

ROLAND CR (ALL OTHER)
no rom reset.

ROLAND CR-80
DEL + REPEAT + POWER ON, THEN PRESS ENTER.

ROLAND CSQ SERIES
no rom reset.

ROLAND D-10
HOLD TUNE/FUNCTION AND WRITE WHILE POWERING ON.

ROLAND D-110
no rom reset.

ROLAND D-20
HOLD TUNE/FUNCTION AND WRITE WHILE POWERING ON.

ROLAND D-5
no rom reset.

ROLAND D-50
TUNE/FUNCTION AND MIDI DATA INIT: HOLD 0 AND DATA TRANSFER, POWER ON. PATCH + REVERB MUST BE LOADED FROM CARD OR SYSEX FILE.

ROLAND D-550
TUNE/FUNCTION AND MIDI DATA INIT: HOLD PATCH BANK 2, PATCH NUMBER6, AND ENTER, POWER ON. PATCH AND REVERB DATA MUST BE LOADED FROM CARD OR SYSEX FILE.

ROLAND D-70
HOLD BANK 8 WHILE POWERING ON. PRESS ENTER, THEN PRESS WRITE TWICE.

ROLAND D2
HOLD WRITE + PRESS SYSTEM. PRESS ENTER TWICE.

ROLAND DDR-30
HOLD #1 BUTTON AND POWER ON.

ROLAND DEP-3
MEMORY NO UP AND DOWN BUTTONS WHILE POWERING ON.

ROLAND DEP-5
MEMORY NO UP AND DOWN BUTTONS WHILE POWERING ON.

ROLAND DJ-70
no rom reset.

ROLAND DJ-70MKII
no rom reset.

ROLAND DM SERIES
no rom reset.

ROLAND DR-202
HOLD MUTE + ROLL AND POWER ON. VALUE DIAL TO SEL

ECT 'ALL', THEN PRESS TAP/ENTER TWICE.

ROLAND DR-5
FRET LEFT + FRET RIGHT + POWER ON; 2 X ENTER.

ROLAND DR-550
HOLD -1 AND +1 AND POWER ON, THEN PRESS START.

ROLAND DR-550MKII
HOLD -1 AND +1 AND POWER ON, THEN PRESS START.

ROLAND DR-660
UTILITY THEN CURSOR TO SELECT (8) INIT; 2 X ENTER.

ROLAND DR-670
HOLD RECORD + STOP/CONT BUTTONS AND POWER ON. PRESS ENTER TWICE.

ROLAND DR-770
PRESS UTILITY AND THEN CURSOR RT TO 9.F.RST. VALUE DIAL TO SELECT ALL, AND THEN PRESS ENTER TWICE.

ROLAND DS-330
HOLD REVERB + SPLIT AND POWER ON; PRESS YES.

ROLAND E-10
HOLD WRITE WHILE TURNING POWER ON.

ROLAND E-12
no rom reset.

ROLAND E-14US
resets at power on.

ROLAND E-15
resets at power on.

ROLAND E-16
resets at power on.

ROLAND E-20
HOLD WRITE + POWER ON.

ROLAND E-28US
resets at power on.

ROLAND E-30

HOLD WRITE + POWER ON.

ROLAND E-35
HOLD REC/PUNCH IN + POWER ON.

ROLAND E-36
RECORDER + POWER ON.

ROLAND E-5
no rom reset.

ROLAND E-56
HOLD WRITE + POWER ON.

ROLAND E-66
RECORD (IN DISK RECORDER SECTION) + POWER ON.

ROLAND E-68US
HOLD WRITE + POWER ON.

ROLAND E-70
HOLD WRITE + POWER ON.

ROLAND E-86
HOLD WRITE + POWER ON.

ROLAND E-96
HOLD WRITE + POWER ON.

ROLAND E300
PRESS UTILITY. USE BUTTONS BELOW 'PAGE' TO SELEC
T FACTORY PRESET. PRESS EXECUTE, THEN OK. WHE
N RESET COMPLETE POWER OFF, THEN ON.

ROLAND E500
PRESS UTILITY. USE BUTTONS BELOW 'PAGE' TO SELEC
T FACTORY PRESET. PRESS EXECUTE, THEN OK. WHE
N RESET COMPLETE POWER OFF, THEN ON.

ROLAND E600
PRESS UTILITY. USE PAGE BUTTONS TO SELECT FACTOR
Y PRESET, THEN EXECUTE.

ROLAND EF303
HOLD SHIFT AND THEN POWER ON. PRESS WRITE TWICE,
THEN POWER OFF AN ON AGAIN.

ROLAND EM-10
HOLD WRITE AND POWER ON.

ROLAND EM-101
no rom reset.

ROLAND EM-15
HOLD THE WRITE BUTTON WHILE TURNING ON THE POWER
.

ROLAND EM-20
HOLD WRITE AND POWER ON.

ROLAND EM-25
HOLD THE WRITE BUTTON WHILE TURNING ON THE POWER
.

ROLAND EM-30
HOLD WRITE AND POWER ON.

ROLAND EM-303
resets at power on.

ROLAND EM-305
resets at power on.

ROLAND EM-50
HOLD WRITE AND POWER ON.

ROLAND EP (ALL OTHER)
no rom reset.

ROLAND EP-3
resets at power on.

ROLAND EP-5
HOLD REC + PLAY, PRESS STRINGS, POWER OFF / ON.

ROLAND EP-7
HOLD REC + PLAY, PRESS STRINGS, POWER OFF / ON.

ROLAND EP-707
resets at power on.

ROLAND EP-75
HOLD REC AND POWER ON.

ROLAND EP-7MKII
HOLD REC + PLAY, PRESS STRINGS, POWER OFF AND ON
.

ROLAND EP-85
HOLD REC AND POWER ON.

ROLAND EP-9
HOLD REC + PLAY, PRESS CHOIR, POWER OFF AND ON.

ROLAND EP-95
HOLD REC BUTTON WHILE POWERING ON.

ROLAND FA76
PRESS MENU THEN UP/DOWN TO FACTORY PRESET. PRESS
F8 TWICE (SELECT THEN EXECUTE) TO RESET.

ROLAND FANTOM
PRESS MENU THEN UP/DOWN TO FACTORY PRESET. PRESS
F8 TWICE (SELECT THEN EXECUTE) TO RESET.

ROLAND FC-100
no rom reset.

ROLAND FC-100MKII
HOLD #1 + #2 + #8 AND POWER ON.

ROLAND FC-200
HOLD #10 AND POWER ON, THEN PRESS CTL PEDAL.

ROLAND FG-10
HOLD CLEAR AND EXIT THEN POWER ON.

ROLAND FG-1000
HOLD CLEAR AND EXIT THEN POWER ON.

ROLAND FP-1
resets at power on.

ROLAND FP-8
PRESS FUNC AND RELEASE HOLD PIANO PRESS FUNC AGA
IN.

ROLAND FP-9
resets at power on.

ROLAND G-600
HOLD WRITE AND POWER ON.

ROLAND G-800
HOLD WRITE, THEN POWER ON.

ROLAND GC-8

no rom reset.

ROLAND GI-10
HOLD PARAMETER + AND -, POWER ON THEN PRESS VALUE +.

ROLAND GM-70
POLY MODE: HOLD PLAY, GENERAL EDIT, + IND EDIT THEN POWER ON. MONO MODE: HOLD TUNE, CONTROL ASSIGN, AND DATA TRANSFER THEN POWER ON.

ROLAND GP-100
HOLD IN PARAMETER KNOB, POWER ON, PRESS WRITE.

ROLAND GP-16
HOLD #6, #7, #8, THEN POWER ON. USE FUNCTION LEFT AND RIGHT TO SELECT "2. ALL FACTORY PRESET" THEN PRESS WRITE 3 TIMES.

ROLAND GP-8
no rom reset.

ROLAND GR (ALL OTHER)
no rom reset.

ROLAND GR-09
HOLD PEDAL #2 THEN POWER ON. PRESS VALUE+ THEN PRESS EDIT/PLAY.

ROLAND GR-1
HOLD WRITE/COPY THEN POWER ON THEN PRESS YES.

ROLAND GR-30
HOLD PEDAL #2, POWER ON. PRESS PATCH + TO SELECT INIT. PRESS EDIT/PLAY, THEN PATCH + AND - SIMULTANEOUSLY.

ROLAND GR-33
PRESS SYSTEM THEN PARAMETER, USE VALUE DIAL TO SELECT ALL. PRESS WRITE TWICE.

ROLAND GR-50
no rom reset.

ROLAND GS-6
no rom reset.

ROLAND GT-3
HOLD MOD AND SFX AND POWER ON. PRESS WRITE.

ROLAND GT-5
HOLD MOD + FEED BACKER/SLOW GEAR, POWER ON. THEN
PRESS WRITE.

ROLAND GX-700
PRESS TUNER/UTILITY. USE PARAMETER LEFT AND RIGHT
TO SELECT FACT INIT. CURSOR TO LEFT, DIAL SYSTEM,
THEN RIGHT AND DIAL P#100. PRESS WRITE THEN TUNER/UTILITY.

ROLAND HP (ALL OTHER)
resets at power on.

ROLAND HP-100
no rom reset.

ROLAND HP-300
no rom reset.

ROLAND HP-400
no rom reset.

ROLAND HS SERIES
no rom reset.

ROLAND JD-800
PRESS DATA TRANSFER. PAGE UP TO SELECT FACTORY
RESET, PRESS YES.

ROLAND JD-990
HOLD EXIT AND PRESS UTILITY. PRESS F6 THEN F5.

ROLAND JP-6
no rom reset.

ROLAND JP-8
no rom reset.

ROLAND JP-8000
HOLD SHIFT, PRESS INIT/BULK. PRESS BUTTON 7, USE
UP/DOWN (SELECT FACTORY RESET), PRESS WRITE
TO SELECT FACTORY PRESETS.

ROLAND JS-30
HOLD RECORD BUTTON (SEQUENCER SECTION), POWER ON
.

ROLAND JUN0-106
no rom reset.

ROLAND JUN0-60
no rom reset.

ROLAND JUN0-1
no rom reset.

ROLAND JUN0-2
no rom reset.

ROLAND JUN0-6
no rom reset.

ROLAND JUPITER-6
no rom reset.

ROLAND JUPITER-8
no rom reset.

ROLAND JV-1000
HOLD NUMBER 8, POWER ON. PRESS ENTER THEN WRITE.

ROLAND JV-1080
PRESS UTILITY. CURSOR DOWN ONCE THEN RIGHT 3 TIMES TO FACTORY PRESET. PRESS ENTER TWICE, THEN UTILITY.

ROLAND JV-2080
PRESS UTILITY. PRESS F6 TWICE TO MENU 3. PRESS F1 THEN F6. IF REQ'D USE VALUE DIAL TO TURN OFF F MEM. PROT. AND PRESS F6 TWICE.

ROLAND JV-30
PRESS CHORUS + REVERB (ABOVE INIT) TOGETHER THEN PRESS VALUE UP.

ROLAND JV-35
PRESS CONTROL + MASTER TOGETHER. USE PARAMETER UP AND DOWN TO SELECT ALL. PRESS VALUE UP.

ROLAND JV-50
PRESS CONTROL + MASTER TOGETHER. USE PARAMETER UP AND DOWN TO SELECT ALL. PRESS VALUE UP.

ROLAND JV-80
HOLD NUMBER 8, POWER ON. PRESS ENTER THEN WRITE.

ROLAND JV-880
PRESS UTILITY, USE DATA DIAL TO SELECT FACTORY P

RESET. PRESS ENTER TWICE.

ROLAND JV-90
HOLD NUMBER 8, POWER ON. PRESS ENTER THEN WRITE.

ROLAND JW-50
PRESS TUNE/FUNCTION. PRESS F5 THEN F4 THEN F3 THEN F4.

ROLAND JX-1
HOLD WRITE AND FLUTE THEN POWER ON.

ROLAND JX-10
no rom reset.

ROLAND JX-3P
no rom reset.

ROLAND JX-8P
no rom reset.

ROLAND KR-100
resets at power on.

ROLAND KR-3000
HOLD FROM AND TO BUTTONS, THEN PRESS WRITE.

ROLAND KR-33
resets at power on.

ROLAND KR-350
HOLD LOAD AND SAVE, THEN PRESS WRITE.

ROLAND KR-3500
HOLD LOAD AND SAVE, THEN PRESS WRITE.

ROLAND KR-370
resets at power on.

ROLAND KR-4500
HOLD LOAD AND SAVE, THEN PRESS WRITE.

ROLAND KR-4700
HOLD LOAD AND EDIT, THEN PRESS SAVE.

ROLAND KR-500
HOLD FROM AND TO, THEN PRESS WRITE.

ROLAND KR-5000

HOLD LOAD AND EDIT, THEN PRESS SAVE.

ROLAND KR-55
HOLD MIDI FUNCTION AND PRESS CARDS (5 SECONDS).

ROLAND KR-5500
HOLD LOAD AND SAVE, THEN PRESS WRITE.

ROLAND KR-575
PRESS FUNCTION; PAGE TO 'FACTORY RESET'. TOUCH EXECUTE, THEN OK.

ROLAND KR-577
PRESS UTILITY; USE BUTTONS BELOW PAGE TO SELECT 'FACTORY PRESET'. PRESS EXECUTE, THEN OK.

ROLAND KR-650
HOLD LOAD AND SAVE, THEN PRESS WRITE.

ROLAND KR-770
HOLD PART VOLUME ACCOMP, PRESS TRACK 2 + 4 BUTTONS SIMULTANEOUSLY. USE PART VOLUME ACCOMP REPEATEDLY TO GET FACTORY SET-UP LOAD. WHEN DONE PWR OFF/ON.

ROLAND KR-977
PRESS FUNCTION; USE PAGE BUTTONS TO 'FACTORY RESET'. TOUCH EXECUTE, THEN OK.

ROLAND LVC-1N
HOLD ENTER BUTTON THEN POWER ON.

ROLAND M-760
HOLD EDIT, PRESS WRITE. PARAMETER UP/DOWN TO SELECT ALL + PRESS WRITE. ON COMPLETION PRESS EDIT TO RETURN TO PLAY.

ROLAND M-DC1
HOLD F3 AND THEN POWER ON.

ROLAND M-GS64
HOLD F3 AND THEN POWER ON.
CONTRIBUTED-: HOLD SELECT AND PRESS F4, PRESS F3 AND THEN PRESS ENTER.

ROLAND M-OC1
HOLD F3 AND THEN POWER ON.

ROLAND M-SE1
HOLD F3 AND THEN POWER ON.

ROLAND M-VS1
HOLD F3 AND THEN POWER ON.

ROLAND MBD1
HOLD F3 AND THEN POWER ON.

ROLAND MC-303
HOLD SHIFT AND THEN POWER ON, THEN PRESS ENTER.

ROLAND MC-307
PRESS SYSTEM, THEN F2 (UTIL). CURSOR DN TO FACTO
RY RESET. PRESS F1 AND THEN F4.

ROLAND MC-50
no rom reset.

ROLAND MC-505
HOLD SHIFT BUTTON AND POWER ON. PRESS ENTER.

ROLAND MC-50MKII
no rom reset.

ROLAND MC-80
no rom reset.

ROLAND MC-80EX
no rom reset.

ROLAND MDC-1
HOLD F3 AND POWER ON.

ROLAND ME-10
HOLD BANK DOWN PEDAL, THEN PRESS WRITE.

ROLAND ME-30
HOLD PARAMETER RIGHT AND VALUE WHILE POWERING ON
. PRESS WRITE/COPY.

ROLAND ME-33
HOLD EZ TONE AND AMP/EFFECT RIGHT WHILE POWERING
ON. THEN PRESS WRITE.

ROLAND ME-5
HOLD PEDALS 1 AND 2, POWER ON; PRESS WRITE IMMED
IATELY.

ROLAND ME-6
HOLD LEFT + DOWN AND POWER ON; THEN PRESS WRITE.

ROLAND ME-6B
HOLD LEFT + DOWN AND POWER ON; THEN PRESS WRITE.

ROLAND ME-8
HOLD LEFT + DOWN AND POWER ON; PRESS WRITE/COPY.

ROLAND ME-8B
HOLD PARAMETER LEFT + DOWN BUTTONS, THEN PRESS WRITE/COPY.

ROLAND ME-X
HOLD PARAMETER LEFT + DOWN AND POWER ON, THEN PRESS WRITE.

ROLAND MGS-64
HOLD F3 AND POWER ON.

ROLAND MK-60
no rom reset.

ROLAND MK-80
HOLD WRITE, PRESS EDIT. HOLD LEFT AND RIGHT CURSOR BUTTONS AND PRESS UP.

ROLAND MKB SERIES
no rom reset.

ROLAND MKS-50
POLY MODE: HOLD NUMBER BUTTONS 4 AND 8 AND POWER ON.

ROLAND MKS-50
MONO MODE: HOLD NUMBER BUTTONS 3 AND 7 AND POWER ON.

ROLAND MMP-2
PRESS SYSTEM UNTIL LIGHTS ORANGE. USE PAGE LEFT/RIGHT BUTTONS TO SELECT INITIALIZE. USE LEFT VALUE TO SELECT ALL; PRESS ENTER TWICE.

ROLAND MP SERIES
no rom reset.

ROLAND MS-1
no rom reset.

ROLAND MSE-1
HOLD F3 AND POWER ON.

ROLAND MSQ-100
no rom reset.

ROLAND MSQ-700
no rom reset.

ROLAND MT-100
HOLD STOP, PRESS DELETE. AFTER THE DISPLAY FLASH
ES "ALL CLEAR" PRESS EXECUTE.

ROLAND MT-120
HOLD REPEAT, SONG (BLUE), AND PLAY, POWER ON. PR
ESS FWD REPEATEDLY UNTIL READS T13. PRESS PLA
Y THEN RECORD, THEN POWER OFF/ON.

ROLAND MT-120S
HOLD REPEAT, SONG (BLUE), AND PLAY, POWER ON. PR
ESS FWD REPEATEDLY UNTIL READS T13. PRESS PLA
Y THEN RECORD, THEN POWER OFF/ON.

ROLAND MT-200
HOLD REPEAT, SONG (BLUE), AND PLAY, POWER ON. US
E DIAL TO SELECT T-15 ON DISPLAY. PRESS PLAY
THEN RECORD, THEN POWER OFF/ON.

ROLAND MT-300
PRESS MENU, DIAL TO FACTORY PRESET. PRESS ENTER
TWICE.

ROLAND MT-32
HOLD MASTER VOLUME, PRESS RHYTHM PART, PRESS PAR
T 1.

ROLAND MT-80
resets at power on.

ROLAND MV-30
no rom reset.

ROLAND MVS-1
HOLD F3 AND POWER ON.

ROLAND OCTAPAD
HOLD MIDI CH AND NOTE NUMBER, POWER ON. POWER OF
F, THEN POWER ON AGAIN.

ROLAND OCTAPAD II
HOLD BOTH VALUE BUTTONS, POWER ON.

ROLAND P-330
no rom reset.

ROLAND P-55
HOLD BOTH INSTRUMENT BUTTONS, POWER ON, THEN PRE
SS PARAM 1.

ROLAND PAD-8
HOLD MIDI CH AND NOTE NUMBER, POWER ON. POWER OF
F, THEN POWER ON.

ROLAND PAD-80
HOLD BOTH VALUE BUTTONS, POWER ON.

ROLAND PC-150
HOLD COMMAND (LEFT), POWER ON.

ROLAND PC-200
HOLD THE 2 BUTTONS UNDER "STANDARD", POWER ON.

ROLAND PIANO PLUS (ALL)
no rom reset.

ROLAND PK-5
HOLD OCT/PARAM AND POWER ON.

ROLAND PK-7
no rom reset.

ROLAND PLANET-P
no rom reset.

ROLAND PLANET-S
no rom reset.

ROLAND PM-16
no rom reset.

ROLAND PMA-5
HOLD VALUE, POWER ON. TOUCH 2 CAL. POINTS TOP RI
GHT + BOTTOM LEFT OF DISPLAY W/ TOUCH PEN. DI
SPAYS COMPLETED THEN INITIALIZE, TOUCH EXEC.

ROLAND PRO-E
HOLD WRITE, POWER ON.

ROLAND R-5
HOLD PAGE + SELECT AND POWER ON. PRESS ENTER TWI

CE AT PROMPTS.

ROLAND R-70
HOLD MIDI + ASSIGN AND POWER ON. PRESS YES TWICE
AT PROMPTS.

ROLAND R-8
HOLD CURSOR PAGE AND PARAM SELECT THEN POWER ON.
PRESS ENTER TWICE.

ROLAND R-880
no rom reset.

ROLAND R-8M
HOLD CURSOR RIGHT AND ENTER, POWER ON. PRESS ENT
ER TWICE AT PROMPTS.

ROLAND RA-50
HOLD WRITE THEN POWER ON.

ROLAND RA-90
HOLD WRITE THEN POWER ON.

ROLAND RA-95
HOLD REC, POWER ON.

ROLAND RD-150
HOLD THE PLAY AND REC BUTTONS WHILE POWERING ON.

ROLAND RSP-550
POWER ON WHILE HOLDING PROG PAGE UP AND DOWN, TH
EN PRESS WRITE.

ROLAND SB-55
POWER ON WHILE HOLDING CLEAR BUTTON.

ROLAND SC-155
POWER IN STANDBY MODE. HOLD BOTH INSTRUMENT BUTT
ONS, PRESS POWER ON AND THEN PRESS ALL.

ROLAND SC-33
HOLD SPLIT AND REVERB WHILE POWERING ON, THEN PR
ESS YES.

ROLAND SC-50
HOLD BOTH INSTRUMENT BUTTONS AND POWER ON. THEN
PRESS ALL.

ROLAND SC-55

HOLD BOTH INSTRUMENT BUTTONS AND POWER ON. THEN
PRESS ALL.

ROLAND SC-55MKII
HOLD BOTH INSTRUMENT BUTTONS AND POWER ON. THEN
PRESS ALL.

ROLAND SDD-320
no rom reset.

ROLAND SH-101
no rom reset.

ROLAND SH-2000
no rom reset.

ROLAND SN700
no rom reset.

ROLAND SP700
no rom reset.

ROLAND SPD-11
HOLD ALL/ENTER WHILE POWERING ON. PRESS ALL/ENTER
AGAIN.

ROLAND SPD-8
HOLD EDIT BUTTON WHILE POWERING ON.

ROLAND SRV-1000
no rom reset.

ROLAND TB-303
no rom reset.

ROLAND TD-10
HOLD SETUP AND EXIT KEYS AND TURN POWER ON, THEN
PRESS F4.

ROLAND TD-7
PRESS SYSTEM. CURSOR TO 'INT' AND PRESS ENTER. C
CURSOR TO 'HIHAT' THEN DATA DIAL TO SELECT 'AL
L'. PRESS ENTER TWICE.

ROLAND TD-8 V CUSTOM
PRESS SETUP THEN [F3 (MENU)]. PRESS INC/+, ROTATE
THE VALUE DIAL, OR PRESS CURSOR TO MOVE THE
CURSOR TO "RESET".

ROLAND	TR-505
HOLD PATTERN GROUP A AND MODE AND POWER ON.	
ROLAND	TR-626
HOLD TRACK #1 AND MODE AND POWER ON.	
ROLAND	TR-707
HOLD TRACK WRITE AND PATTERN 1 AND POWER ON.	
ROLAND	TR-727
HOLD TRACK WRITE AND PATTERN 1 AND POWER ON.	
ROLAND	TR-808
no rom reset.	
ROLAND	TR-909
HOLD TRACK #1 AND PATTERN #1 AND POWER ON.	
ROLAND	U-110
HOLD THE EDIT AND PART BUTTONS AND POWER ON.	
ROLAND	U-20
no rom reset.	
ROLAND	U-220
no rom reset.	
ROLAND	VP-70
HOLD MIDI, PLAY, AND VOICE EXP AND POWER ON.	
ROLAND	VS-1680
no rom reset.	
ROLAND	VS-1680EX
no rom reset.	
ROLAND	VS-1824
no rom reset.	
ROLAND	VS-1824CD
no rom reset.	
ROLAND	VS-1880
no rom reset.	
ROLAND	VS-2480
no rom reset.	
ROLAND	VS-2480CD

no rom reset.

ROLAND VS-840
no rom reset.

ROLAND VS-840EX
no rom reset.

ROLAND VS-840GX
no rom reset.

ROLAND VS-880
no rom reset.

ROLAND VS-880EX
no rom reset.

ROLAND VS-890
no rom reset.

ROLAND VT-1
HOLD PRESET/USER BUTTON AND POWER ON.

ROLAND W-30
no rom reset.

ROLAND W-50
PRESS CONTROL AND MASTER BUTTONS SIMULTANEOUSLY.
USE PARAMETER UP AND DOWN BUTTONS TO SELECT A
LL. PRESS VALUE UP BUTTON.

ROLAND XP-50
PRESS DISK UTIL, SELECT SOUND, THEN PROTECT, SET
MEM PROTECT OFF. EXIT, SELECT PRESET AND PRES
S ENTER. (REMEMBER TO SET MEM PROTECT BACK ON).

ROLAND XV-5050
PRESS UTILITY AND CURSOR LEFT BUTTONS. VALUE DIA
L TO SELECT FACTORY RESET AND PRESS ENTER TWI
CE.

ROLAND XV-5080
PRESS SYSTEM/UTILITY SO LIGHT BLINKING. PRESS F6
AND THEN F5. PRESS F6 (EXECUTE) AGAIN.

ROLAND XV-88
PRESS UTILITY, CURSOR DOWN TO UTIL PAGE 2. PRESS
4 (BASS), PRESS ENTER TWICE.

YAMAHA 02R
HOLD "CURSOR LEFT" AND POWER ON.

YAMAHA CLP-100
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-121
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-121S
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-122
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-122S
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-123
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-124
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-133
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-134
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-152
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-152S
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-153
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-153S
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-153SG
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-154
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-154F

HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-154S
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-155
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-156
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-157
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-158
HOLD KEY "F0" OR KEY "B1" AND POWER ON.

YAMAHA CLP-20
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-250
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-260
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-30
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-311
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-350
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-360
HOLD KEY "F0" AND POWER ON.

YAMAHA CLP-411
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-500
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-511
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-550
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-555
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-560
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-570
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-611
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-705
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-711
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-760
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-811
HOLD KEY "B1" AND POWER ON.

YAMAHA CLP-911
HOLD KEY "B1" AND POWER ON.

YAMAHA CLW-12
HOLD KEY "B1" AND POWER ON.

YAMAHA CLW-14
HOLD KEY "B1" AND POWER ON.

YAMAHA CS1X
HOLD BUTTONS 7, 8, AND 9, AND POWER ON.

YAMAHA CS2X
HOLD BUTTONS 7, 8, AND 9, AND POWER ON.

YAMAHA CVP-105
HOLD DOWN THE RIGHTMOST KEY (C7) AND POWER ON.

YAMAHA CVP-35
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-45
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-49
HOLD KEY "F0" AND POWER ON.

YAMAHA CVP-50
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-55
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-59
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-65
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-69
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-69A
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-70
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-75
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-79
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-79A
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-83
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-83S
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-85
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-85A
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-87
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-87A

HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-89
HOLD KEY "B1" AND POWER ON.

YAMAHA CVP-89WH
HOLD KEY "B1" AND POWER ON.

YAMAHA D2040
PRESS 'PEQ/D.ATT' KEY OF CHANNEL 1 AND 'LIMIT/CO
MP' OF CHANNEL 3 AND POWER ON.

YAMAHA D5000
PRESS STORE AND POWER THEN PRESS RECALL.

YAMAHA DD-11
no rom reset.

YAMAHA DDL3
RUN TEST PROGRAM. PRESS 'RECALL' AND THEN PRESS
'STORE'.

YAMAHA DEQ5
HOLD THE 'L' AND 'FLAT' KEYS AND POWER UNIT ON.
PRESS 'RECALL'.

YAMAHA DEQ5E
RUN TEST MODE. WHEN TEST 10 IS PERFORMED, UNIT I
S INITIALIZED AND FACTORY PRESETS ARE RESTORE
D.

YAMAHA DEQ7
HOLD DELAY/LEVEL AND PROTECT ON/OFF, POWER ON.

YAMAHA DMP-11
PRESS FADER FLIP, PARAMETER LEFT, POWER ON.

YAMAHA DMP-7
PRESS FADER FLIP, PARAMETER LEFT, POWER ON.

YAMAHA DMP9-16/8
PRESS MEMORY [RECALL], RETURN [SEL], [UTILITY],
THEN POWER ON.

YAMAHA DOU10
PRESS SHIFT AND POWER ON.

YAMAHA DTS70
PRESS UTILITY AND STORE WHILE POWERING ON.

YAMAHA DX-7II
INSERT ROM CARTRIDGE AND POWER ON.

YAMAHA DX-7S
INSERT ROM CARTRIDGE AND POWER ON.

YAMAHA EMP-700
PRESS F1 AND ^ WHILE POWERING ON.

YAMAHA FX-500
HOLD COMP AND MOD WHILE POWERING ON.

YAMAHA FX-770
HOLD COMP AND PLAY WHILE POWERING ON.

YAMAHA GW-10
HOLD CHO WHILE POWERING ON.

YAMAHA GW-33
HOLD DOWN/NO AND UP/YES WHILE POWERING ON.

YAMAHA MDP-2
HOLD SHIFT AND POWER ON.

YAMAHA MFC-10
HOLD MEMORY, EDIT, AND FC EDIT AND POWER ON.

YAMAHA MLP-11
HOLD KEY "B1" AND POWER ON.

YAMAHA MLP51
HOLD KEY "F0" AND POWER ON.

YAMAHA MU-90
HOLD ENTER AND UTIL WHILE POWERING ON.

YAMAHA P-100
HOLD KEY "B1" AND POWER ON.

YAMAHA P-150
HOLD KEY "B1" AND POWER ON.

YAMAHA P-300
HOLD KEY "B1" AND POWER ON.

YAMAHA P-500
HOLD KEY "B1" AND POWER ON.

YAMAHA PDP-300
HOLD KEY "F0" AND POWER ON.

YAMAHA PDP-400
HOLD KEY "B1" AND POWER ON.

YAMAHA PDP-500
HOLD KEY "B1" AND POWER ON.

YAMAHA PROMIX 01
PRESS STORE AND INC+ WHILE POWERING ON.

YAMAHA PSR-220
PRESS YES AND NO WHILE POWERING ON.

YAMAHA PSR-230
PRESS YES AND NO WHILE POWERING ON.

YAMAHA PSR-410
HOLD [+] AND [-] AND POWER ON.

YAMAHA PSR-420
HOLD [+/YES] AND [-/NO] AND POWER ON.

YAMAHA PSR-510
HOLD [+] AND [-] AND POWER ON.

YAMAHA PSR-520
HOLD [+/YES] AND [-/NO] AND POWER ON.

YAMAHA PSR-530
HOLD RIGHT-MOST WHITE KEY ON THE KEYBOARD WHILE
TURNING ON THE POWER.

YAMAHA PSR-6000
UTILITY MODE, RECALL PRESET DATA, SELECT ALL DATA.

YAMAHA PSR-620
HOLD [+/YES] AND [-/NO] AND POWER ON.

YAMAHA PSR-6300
HOLD KEY "C6" AND POWER ON.

YAMAHA PSR-70
HOLD KEY "C5" AND POWER ON.

YAMAHA PSR-9000
HOLD DEMO AND POWER ON.

YAMAHA PSR-A3
HOLD [+ / YES] AND [- / NO] AND POWER ON.

YAMAHA REV-100
PRESS STORE BUTTON WHILE POWERING ON. THEN PRESS
V AND STORE.

YAMAHA RX-8
HOLD STOP / CONTINUE, +1 / YES, AND -1 / NO AND POWER
ON.

YAMAHA SPX-90
HOLD BALANCE, FOOT TRIGGER AND POWER ON.

YAMAHA SPX-90II
HOLD BALANCE, FOOT TRIGGER AND POWER ON.

YAMAHA SPX990
also test #8 is ram initialization.

YAMAHA TMX
HOLD UTILITY AND STORE THEN POWER ON.

YAMAHA YDP-200
HOLD KEY "F0" OR KEY "B1", WHILE POWERING ON.

YAMAHA YDP-300
HOLD KEY "F0" OR KEY "B1", WHILE POWERING ON.

YAMAHA YDP-301
HOLD KEY "B1", WHILE POWERING ON.

YAMAHA YDP-88
HOLD KEY "B1", WHILE POWERING ON.

YAMAHA YDP-88II
HOLD KEY "B1", WHILE POWERING ON.

ZOOM 505
HOLD THE STORE BUTTON WHILE POWERING ON. DISPLAY
FLASHES "AL"; PRESS STORE AGAIN.

ZOOM 506II
HOLD STORE BUTTON WHILE PLUGGING IN ADAPTOR. PRE
SS STORE ONCE MORE.

mick

Ranger Audio Enterprises
<http://www.rangeraudio.com>

Backups should be performed BEFORE executing factory resets or restoring factory presets data.

This information is provided as a courtesy. NO claims are made as to the accuracy of this data.

Feed a hungry child for FREE in just seconds,SECONDS !!!
<http://www.thehungersite.com>

Coffee Break: <http://www.bloggingnetwork.com/Blogs/Affil/?7534>