CHANNEL 1

INPUT
LINE
LINE B
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

CHANNEL 2

INPUT
LINE
PHONO
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

CHANNEL 3

INPUT
LINE
PHONO
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

CHANNEL 4

INPUT
LINE
LINE B
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

CHANNEL 5

INPUT
LINE
MICRO
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

CHANNEL 6

INPUT
LINE
MICRO
SELECT
LEVEL
0 0 MAX
HIGH
EQUALIZER
MID
LOW
ON
PFL
10 9 8 7 6 5 4 3 2 1 0

RODEC®

POWER
ON
OFF

BALANCE

C
LEFT RIGHT

PHONES

PFL MIX
SELECT

4 5 6
3 7
2 8
1 9
0 10
LEVEL

OUTPUT

VU

LEFT RIGHT
+8
+5
+3
+1
0dB
-1
-3
-5
-7
-10
-15
-20
POWER

MASTER 1

10 9 8 7 6 5 4 3 2 1 0

MASTER 2

10 9 8 7 6 5 4 3 2 1 0

BX-14

CROSSFADER

CH 1-2 CH 3-4