

CHANNEL 1

INPUT LINE LINE B

SELECT LINE LINE B

LEVEL

0 0 MAX

HIGH

MID

LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0

CHANNEL 2

INPUT LINE PHONO

SELECT LINE PHONO

LEVEL

0 0 MAX

HIGH

MID

LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0

CHANNEL 3

INPUT LINE PHONO

SELECT LINE PHONO

LEVEL

0 0 MAX

HIGH

MID

LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0

CHANNEL 4

INPUT LINE LINE B

SELECT LINE LINE B

LEVEL

0 0 MAX

HIGH

MID

LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0

CHANNEL 5

INPUT LINE MICRO

SELECT LINE MICRO

LEVEL

0 0 MAX

HIGH

MID

LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0

CHANNEL 6

INPUT LINE MICRO

SELECT LINE MICRO

LEVEL

0 0 MAX

HIGH

MID


LOW

ON

PFL

EQUALIZER

10 9 8 7 6 5 4 3 2 1 0



RODEC [®] ON POWER
OFF

BALANCE

C

LEFT RIGHT

PHONES

PFL MIX

SELECT

4 5 6

3 7

2 8

1 9

0 10

LEVEL

OUTPUT

VU

LEFT RIGHT

+8

+5

+3

+1

0dB

-1

-3

-5

-7

-10

-15

-20

-POWER-

MASTER 1

10 9 8 7 6 5 4 3 2 1 0

MASTER 2

10 9 8 7 6 5 4 3 2 1 0

BX-14

CROSSFADER

CH 1-2 CH 3-4