



IM INSTALL THE LAST PIONNER DRIVERS AND MIIDI FILT FOR TRAKTOR BEFORE THAT:

1:

AUDIO SETUP: APPEARS JUST “LINEA(PIONEER XDJ-AERO (WASAPI (SHARE MODE)



2: OUTPUT ROUTING: INTERNAL JUST APPEAR TWO OPTIONS. LINE 1 AND LINE 2. WHY??????



3. EXTERNAL IS THE SAME, JUST APPEAR 2-channel soundcard available, WHY? HELP ME PLEASE.
Thanks. So if i click that configuratios i cant use correctly the two aero decks to make my dj set and run it traktor correctly. Please help me because this i bought tha last trakto and i dont wan to lost my money. Thanks

