






the ENTERTAINER 8 - 13

SCHEMATIC DIAGRAMS




CODE	TYPE
TR1	BC172C
TR2-3	BC208B
DA1-3	BA130
DA4	BZX83CAV3
IC1	M254AG





BRASS ARPEGGIO
MODULATOR

CODE	TYPE
TR11	BC 208 B
TR12	BC 208 B
TR13	BC 205 A
TR14	BC 173 C
IC11	CA 3080



PIANO-HARPSY ARPEGGIO
MODULATOR

CODE	TYPE
TR11	BC 208 B
TR12	BC 205 A
TR13	BC 173 C
DI1	BA 130
IC11	CA 3080

CHORDS

ORCHESTRA


CODE	TYPE
TRN1-2	BC205 A
DN1	BA130

PIANO

HARPSY

ON

PAUSE



elgam

LOMETO 11/01/79
91681
(41 9768)

SWITCHES

076









SE 44









SHEET N°2

15-9-78

Tram. Autom. 1

Alcornoque





NOTE
THE SAME ASSEMBLY FOR EG-286
CHORDS MODULATOR PRINTED CIRCUIT

elgamo

ASSEMBLY OF
PRINTED CIRCUIT
SHEET NO. 11
ID 10 78