

MOPHO PARAMETER LIST

-	NAME	OUTPUT MESSAGE	RANGE	CH	PORT	BUTTON	AFT	C.Click
R1	Frequency	CC 102(66)	0(00) - 127(7F)	3	1	-	-	-
R2	Resonance	CC 103(67)	0(00) - 127(7F)	3	1	-	-	-
R3	Keyboard Amt	CC 104(68)	0(00) - 127(7F)	3	1	-	-	-
R4	Audio Mod	CC 105(69)	0(00) - 127(7F)	3	1	-	-	-
R5	Osc Mix	CC 28(1C)	0(00) - 127(7F)	3	1	-	-	-
R6	Noise Level	CC 29(1D)	0(00) - 127(7F)	3	1	-	-	-
R7	Sub Osc 1	CC 30(1E)	0(00) - 127(7F)	3	1	-	-	-
R8	Sub Osc 2	CC 31(1F)	0(00) - 127(7F)	3	1	-	-	-
R9	BPM	CC 14(0E)	0(00) - 127(7F)	3	1	-	-	-
S1	Osc 1 Freq	CC 20(14)	0(00) - 127(7F)	3	1	-	-	-
S2	Osc 1 Freq Fine	CC 21(15)	0(00) - 127(7F)	3	1	-	-	-
S3	Osc 1 Shape	CC 22(16)	0(00) - 127(7F)	3	1	-	-	-
S4	Glide 1	CC 23(17)	0(00) - 127(7F)	3	1	-	-	-
S5	Osc 2 Freq	CC 24(18)	0(00) - 127(7F)	3	1	-	-	-
S6	Osc 2 Freq Fine	CC 25(19)	0(00) - 127(7F)	3	1	-	-	-
S7	Osc 2 Shape	CC 26(1A)	0(00) - 127(7F)	3	1	-	-	-
S8	Glide 2	CC 27(1B)	0(00) - 127(7F)	3	1	-	-	-
S9	Clock/Divide	CC 15(0F)	0(00) - 127(7F)	3	1	-	-	-
A1	-	NO ASSIGN	-	-	-	-	-	-
A2	-	NO ASSIGN	-	-	-	-	-	-
A3	-	NO ASSIGN	-	-	-	-	-	-